












ASSEMBLY INSTRUCTION

<<Before assembling, read all the instruction>>

<p>STEP1</p> 	<p>STEP2</p> 	<p>STEP3</p> 																																												
<p>STEP4</p> 	<p>STEP5</p> 	<p>STEP6</p> 																																												
<p>STEP7</p> 	<p>STEP8</p> 	<p>STEP9</p> 																																												
<p>STEP10</p> 	<p>STEP11</p> 	<table border="1"> <tr> <td></td> <td></td> <td></td> </tr> <tr> <td>Ax1PC</td> <td>Bx1PC</td> <td>Cx1PC</td> </tr> <tr> <td></td> <td></td> <td></td> </tr> <tr> <td>Dx1PC</td> <td>Ex1PC</td> <td>Fx1PC</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>Gx1PC</td> <td>gx1PC</td> <td>ax1PC</td> <td>jx1PC</td> <td>bx24PCS</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>fx1PC</td> <td>ex2PCS</td> <td>mx2PCS</td> <td>hx1PCS</td> <td>nx8PCS</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>dx2PCS</td> <td></td> <td></td> <td></td> <td></td> </tr> </table>						Ax1PC	Bx1PC	Cx1PC				Dx1PC	Ex1PC	Fx1PC						Gx1PC	gx1PC	ax1PC	jx1PC	bx24PCS						fx1PC	ex2PCS	mx2PCS	hx1PCS	nx8PCS						dx2PCS				
Ax1PC	Bx1PC	Cx1PC																																												
Dx1PC	Ex1PC	Fx1PC																																												
Gx1PC	gx1PC	ax1PC	jx1PC	bx24PCS																																										
fx1PC	ex2PCS	mx2PCS	hx1PCS	nx8PCS																																										
dx2PCS																																														

In the unlikely event of missing parts please contact spareparts@premierhousewares.co.uk. Detailing: when and where purchased, stock code, detail of missing piece(s), full name and address.