





































ASSEMBLY INSTRUCTION

<<Before assembling ,read all the instruction>>

Components:

STEP1 		STEP2 		STEP3 		STEP4 		
STEP5 		STEP6 		STEP7 		STEP8 		
STEP9 		STEP10 		STEP11 		OK! 		
 Ax1pc		 Bx1pc		 Cx1pc		 Dx1pc		
 Ex1pc		 Fx1pc		 Hx1pc		 Ix1pc		
 Gx1pc		 ax2pcs	 bx16pcs	 dx2pcs	 ex2pcs	 fx1pcs	 gx2pcs	
 hx9pcs	 jx2pcs	 kx6pcs	 lx8pcs	 ox1pcs	 rx1pcs	 tx1pcs	 mx2pcs	 nx2pcs

**In the unlikely event of missing parts please contact
spareparts@premierhousewares.co.uk. Detailing: when and
where purchased, stock code, detail of missing piece(s), full
name and address.**