


2403841/2403844

# ASSEMBLY INSTRUCTION


《Before assembling, read all the instruction》



**ATTENTION: KEEP OUT OF DIRECT SUNLIGHT**

In the unlikely event of missing parts please contact [spareparts@premierhousewares.co.uk](mailto:spareparts@premierhousewares.co.uk).

Detailing: When and where purchased, stockcode, detail of missing piece(s), full name and address.




A



∅15x12mm  
24pcs

B




M6x35mm  
20pcs

C




∅6x30mm  
20pcs

D



∅4x35mm  
4pcs

E




∅4x25mm  
16pcs

F



∅12x10mm  
12pcs

G




8pcs

H




∅3x10mm  
36pcs

I



∅4x30mm  
12pcs

J




4pcs

K




8pcs

L




∅4x16mm  
24pcs

M




390mm  
3pcs

N




390mm  
3pcs

O




2pcs


Step 1




Step 3




Step 2




Step 4




Step 5




Step 7




Step 6




Step 8




Step 9




Step 11




Step 10




Step 12




### Step 13




### Step 14




### Step 15




Step 16




Step 18




Step 17



Step 19



## Step 20



## Step 21

