




2404412

ASSEMBLY INSTRUCTION


《Before assembling, read all the instruction》




3



2



4



ATTENTION: KEEP OUT OF DIRECT SUNLIGHT
In the unlikely event of missing parts please contact spareparts@premierhousewares.co.uk. Detailing: when and where purchased, stockcode, detail of missing piece(s), full name and address